



- NOTES**
- FOR ACTUAL SEE 6954
 - THE SET IS SHOWN WIRED FOR SIMPLEX 0.60 AMP. NEUTRAL SIGNAL LINE ON TERMINALS 6 AND 7 OF THE 15441 TERMINAL STRIP FOR 0.20 AMP. NEUTRAL SIGNAL LINE MOVE THE P WIRE FROM TERMINAL 8 TO TERMINAL 9 OF THE 15441 TERMINAL STRIP. ALSO MOVE THE BL WIRE FROM TERMINAL 5 OF THE POWER RESISTOR 181816 TO TERMINAL 4
 - FOR FULL DUPLEX OPERATION CONNECT THE SEND SIGNAL LINE TO TERMINAL 4 AND 3 OF THE 15441 TERMINAL STRIP. MOVE THE W-BL WIRE FROM TERMINAL 4 TO 5 AND THE BR-Y WIRE FROM TERMINAL 3 TO 5 ON THE 15441 TERMINAL STRIP
 - ON KR SETS ALL W. 5 CONTACTED READER WIRING IS NOT USED
 - BY SYMBOL AROUND LEADS INDICATES MARKING ON CONNECTORS
 - ALL CAPACITANCE VALUES IN MFD UNLESS OTHERWISE SPECIFIED
 - ALL RESISTORS 1/2 WATT AND RESISTANCE VALUES IN OHMS UNLESS OTHERWISE SPECIFIED
 - ON KR SETS USE 181818 CABLE ASSEMBLY
 - THESE CONNECTIONS ARE MADE AS OPTION BY THE CUSTOMER AND OR THE FACTORY
 - 0.20 AMP SIGNAL LINE OPTION 1
 - 0.60 AMP SIGNAL LINE OPTION 2
 - THIS IS AN 8 LEVEL UNIT
 - THESE WIRES ARE IN THE DISTRIBUTOR CABLE AS SUPPLIED
 - THIS FUSE NOT INCLUDED ON SETS
 - WIRING SHOWN AS KR 15 FOR EVEN CARRY KEYBOARDS
 - FURNISH US VOLTAGE 10% SO CYCLE EXCEPT 50 CYCLE ON 55781, 55782, 55783 AND TACTA3 KR SETS
 - APPROPRIATE FUSE IN 181812 FUSE HOLDER NOT INCLUDED IN EARLY SETS MOTOR FUSE, FUSE VALUE PART NO. 18224 2.0 AMP, 18225 1.0 AMP, 18226 1.0 AMP, 18227 1.0 AMP
 - NETWK. 153631
 - 60 CYCLE READER TRIP COIL RESISTANCE 650 Ω. 50 CYCLE READER COIL RESISTANCE CHANGE FROM 650 TO 780 Ω FOR IMPROVED 50 CYCLE OPERATION

geveke

Geveke Electronics
and Automation
INTERNATIONAL

SCHMATIC WIRING DIAGRAM
MODEL 33 WITH UCC 6 (SINGLE CURRENT).

WERK No.		A3_KC/5018/T	
SCHAAL			
Get.	28.9.73		
Gec.			
Gez.			
AANTAL BL.			
BLAD			